

## Adjusting Superarm Before Use

The size 50 c"m (20 Inch) Is The Minimum Size Between The Superarm Lower Beam, End The Lower Point Of The Top Ceiling

